

# Step 1: Unzip Carry bag and remove Tent

## SETUP

### 2 OPEN E-Z UP® SHELTER


- A With a partner on the opposite side, grasp the bottom of the diamond-shaped area of outer trusses near the "OPEN HERE" sticker.
- B Lift the frame up slightly and step backwards until the shelter is almost fully opened. Gently shake the shelter while opening. Be careful not to pinch fingers!



## SETUP

### 3 SECURE AUTO SLIDER® PULL PIN

- A Fold up the fabric top corner to expose the Auto Slider® Pull Pin.
- B Lift shelter corner slightly off the ground and engage the Auto Slider® Pull Pin by pushing up on the frame trusses with one hand while holding down the top of the frame leg with the other hand. The pins will auto-engage when aligned with the holes on the frame legs.
- C After the Auto Slider® Pull Pin has locked into place, pull the fabric top down over the frame leg, making sure to align and secure the hook and loop strips on the fabric top to the frame.
- D Repeat on all remaining corners.



## IMPORTANT INFORMATION:

Read this information before proceeding. It is the user's responsibility to take the following precautions at all times.

- Always stake or weigh down your shelter securely. Do not use in potentially heavy rain or snow storms or in strong wind conditions. If there is any question, take shelter down and store safely away from the elements.

- Wind, rain & snow can damage the E-Z UP® Instant Shelter® and may result in injury to you or others. Therefore, do not rely on shelter for protection in heavy rain or prolonged storms of any kind.

- The E-Z UP® Instant Shelter® is designed as a temporary shelter. Do not leave unattended for extended periods.

- Use caution when handling the E-Z UP® folding frame.

- Avoid pinching hands or fingers as frame opens or closes.

- Do not use shelter in a lightning storm.

- Do not build fires within shelter enclosure.

## SETUP

### 4 SECURE TOP STRAPS; EXTEND LEG

- A Secure the four hook and loop straps on the top to the four peak poles.
- B With a partner, lift the two adjacent outer legs up off the ground simultaneously to about waist height.
- C Slide the lower/inner legs out until the leg adjustment toggle buttons lock at selected height. There are 3 adjustment settings for each leg.
- D Repeat on the remaining legs.

**Note:** It is recommended that you use genuine E-Z UP® Deluxe Weight Bags and/or heavy-duty Stake Kits to secure your Instant Shelter® product.



## TAKE DOWN

### 5 COLLAPSE SHELTER LEGS

- A With a partner, slightly lift two adjacent corner legs simultaneously.
- B Depress the toggle button and slide lower/inner legs into upper/outer legs, making sure to do two legs at a time on the same side. Keep the toggle button depressed while retracting leg.
- C Repeat on remaining legs.



## TAKE DOWN

### 6 RELEASE AUTO SLIDER® PULL PIN

- A With one hand, slightly push up on the truss near the Auto Slider® Pull Pin to relieve pressure.
- B With the other hand, release the Auto Slider® Pull Pin by pulling the ring and push down to ensure that it is disengaged.
- C Repeat on remaining legs.



## TAKE DOWN

### 7 CLOSING SHELTER

- A Grasp the frame on the top of the diamond-shaped area of center trusses on the opposite sides near the "CLOSE HERE" sticker.
- B Lift the shelter up slightly, and shake it while stepping towards your partner until the shelter is approximately 3/4 closed. Be careful not to pinch fingers!
- C Grasp the two outer legs, and push the frame together until it is fully closed.
- D Give your shelter a hug and place it in the Roller Bag provided.



Let Tent top & Frame dry completely before closing or storing to avoid mildew